

AAEN GAUGES

Aaen Battery Charge Kit

544-P10641

\$99.95-H

Your EFI is dependent on good voltage to function properly. If the voltage drops, the standard charging circuit will not be able to supply enough charge to keep the voltage up. The "Supercharge Kit" consists of an electronic box that senses low battery voltage, and then supplies additional charge form the separate accessory circuit.



THE PODD

MODEL	# OF HOLES	HOLE SIZE	TCI #	RETAIL
A/C Prowler EXT '90-92	2	2"	756-7003	\$30.90-H
A/C ZRT 600/800, '95-'98, Thundercat '96-98, Powder Extreme '98	3	2"	756-7002	\$54.95-H
A/C ZR '93,EXT '94-97,Wildcat '95-96,Powder Special '95-97	2	2"	756-7001	\$54.95-H
Pol Indy's Original Style Hood	3	2"	756-7007	\$54.95-H
Pol '96-97 Storm, XcR, 600SP, 970 Ultra Special, Ultra Touring	3	2"	756-7017	\$55.75-H
Pol '97-99 With Larger Speedo & Tach	2	2"	756-7018	\$55.75-H
Pol '97-99 With Larger Speedo & Tach	3	2"	756-7019	\$55.75-H
Yam Exciter & Vmax 4	1	2"	756-7011	\$48.50-H
Yam Exciter & Vmax 4	1	3"	756-7012	\$55.30-H
Yam Vmax '97-00	2	2"	756-7020	\$59.90-H
Yam Vmax '97-00	3	2"	756-7021	\$59.90-H
Yam Vmax 500/600/800 '92-96, Vmax 4 750/800 '92-97	2	2"	756-7016	\$47.50-H
Bullet Case - Handlebar Mounting	1	2"	756-6002	\$25.95-H



756-7001



756-7011



756-7003



756-7016



756-7017



756-7018



756-7019



756-6002/4