



IGNITION COILS & LIGHTING COILS

Model	Year	External Ignition	Internal Ignition	Stator & Lightning Coils
Coils Codes: A = Primary A B = Primary B CH = Charging G = Generator IP Ignition & Primary L = Lighting P = Pulsation PR = Primary S = Source SR = Sensor ST = Stator				
Arctic Cat				
All F/C Models			01-096(SR)	
Bearcat 340, 440	95-97	01-143-120	01-105-01(PR)	
Bearcat 340, 440, I, II	98-00	01-143-63		
Bearcat 550	95-96	01-143-120	01-105-01(PR)	01-145-07(ST)
Bearcat Widetrack	96-97	01-143-120	01-105-01(PR)	01-145-07(ST)
Bearcat 550, Widetrak	98-02	01-143-120		01-145-07(ST)
Bearcat 570, XT	04-13	01-143-157		
Bearcat Widetrack (all w/Suzuki 4 Stroke 660)	03-08	01-143-161		
Bearcat Widetrack	2008	01-143-162		
Cheetah	1972	01-143-111		
Cheetah	73-74	01-143-01		
Cheetah Wanel 295	1975	01-143		
Cheetah 440, 500	1976	01-143-11	01-143-30(PR)	
Cheetah F/C	76-78	01-143-11		
Cheetah F/C	1986	01-143-08	01-098-01(A) 01-098-02(B)	
Cheetah L/C	1986	01-143-08	01-092(P) 01-100(PR)	01-107-03(L)
Cheetah L/C	87-88	01-143-120	01-092(P) 01-100(PR)	01-107-03(L)
Cheetah F/C	87-89	01-143-08		
Cheetah F/C	1990	01-068-02		
Cheetah Touring	88-90		01-105-01(PR)	
Cheetah Touring	91-93	01-143-53		01-143-48(L)
Cheetah 340, 440	93-96	01-143-120		
Cheetah 340, 440	1994		01-105-01(PR)	01-145-07(ST)
Cheetah 550	1994		01-105-01(PR)	01-145-07(ST)
Cougar	85-87	01-143-08	01-098-01(A) 01-098-02(B)	
Cougar	88-89	01-143-120	01-105-01(PR)	
Cougar, Mountain Cat	1990	01-068-02	01-105-01(PR)	
Cougar, Mountain Cat 440	91-94	01-143-53		01-143-48(L)
Cougar, Mountain Cat 550	95-97	01-143-120	01-105-01(PR)	01-145-07(ST)
Cougar 2-Up	1996		01-105-01(PR)	
Cross Country 340	1976	01-143-06	01-092(P) 01-098(PR)	01-102(L)
Cross Country 340	1977	01-143-11		01-093(L)
Cross Country 440	1979	01-143-08	01-143-30(PR)	01-093(L)
Crossfire 500 EFI	07-09	01-143-162		01-145-13(ST)
Crossfire 600 (CF6), 700 (all)	2006	01-143-162		
Crossfire 600 (CF6), 700 EFI	07-09	01-143-162		01-145-13(ST)
Crossfire 800 EFI, 1000 EFI (CF8)	07-11	01-143-76		01-145-13(ST)
El Tigre	1974			
El Tigre 4000, 5000, 440 Z (440, 500)	1976	01-143-11	01-143-30(PR)	
El Tigre 4000, 5000, 440 Z (440, 500)	1977	01-143-08	01-143-30(PR)	
El Tigre 250/340 Z (L/C)	1977		01-143-30(PR)	
El Tigre 5000 F/A	78-81	01-143-08	01-099 (IP)	
El Tigre 5000	78-79	01-143-11	01-143-30(PR)	01-093(L)
El Tigre 5000	80-81	01-143-11		01-093(L)
El Tigre 5000	1987	01-143-120		
El Tigre 6000	78-79	01-143-08	01-143-30(PR)	01-093(L)
El Tigre 6000	80-81/84-85	01-143-08	01-092(P)	01-102(L)
El Tigre 6000	1986	01-143-08	01-092(P) 01-100(PR)	
El Tigre 6000 L/C	87-88	01-143-120	01-092(P) 01-100(PR)	01-107-03(L)



IGNITION COILS & LIGHTING COILS

Model	Year	External Ignition	Internal Ignition	Stator & Lightning Coils
Coils Codes: A = Primary A B = Primary B CH = Charging G = Generator IP Ignition & Primary L = Lighting P = Pulsation PR = Primary S = Source SR = Sensor ST = Stator				
Arctic Cat				
El Tigre 6000	1989		01-105-01(PR)	
El Tigre L/C	80-81	01-143-08	01-092(P) 01-100(PR)	01-102(L)
El Tigre EXT	1989		01-092(P) 01-100(PR)	01-107-03(L)
El Tigre EXT Special	90-91	01-143-120	01-105-01(PR)	01-107-03(L)
El Tigre EXT, Mountain Cat	90-91	01-143-120	01-105-01(PR)	
El Tigre Z	1975		01-101(P)	
EXT, Mountain Cat, Special 550	92-93	01-143-120	01-105-01(PR)	
EXT 550, 580, 580Z, EFI, Powder Special	93-96	01-143-120	01-105-01(PR)	
EXT 580 (not FEI models), MC, Special	92-96			01-145-07(ST)
EXT 600 Triple Touring	97-99	01-143-61 coil 1 01-143-62 coil 2		
EXT Powder Special	1996			01-145-07(ST)
F570	08-13	01-143-157		
F8 (all)	07-13	01-143-76		01-145-13(ST)
F10, F1000 (all)	07-09	01-143-08		01-145-13(ST)
Firecat 500, 700, Sno-Pro EFI	2003	01-143-63		
Firecat 500, Sno-Pro	04-06	01-143-162		
Firecat 600, 700 Sno-Pro EFI	04-06	01-143-162		01-145-05(ST)
Firecat 700 EFI	2003	01-143-63		01-145-05(ST)
Firecat 700 EFI	2004			01-145-05(ST)
Jag 275, 340	1976	01-143-08	01-143-30(PR)	
Jag 3000 F/C	79-80	01-143-11	01-092(P)	
Jag F/C (all)	79-81	01-143-11		
Jag F/A (all)	76-77	01-143-08	01-143-30(PR)	01-093(L)
Jag F/A (all)	78-80	01-143-08		01-102(L)
Jag 2000 F/A, Jag 3000 F/A	79-80	01-143-08	01-092(P) 01-098(PR)	01-102(L)
Jag 340, 440	85-86	01-143-08	01-098-01(A) 01-098-02(B)	
Jag 340 (all)	1987	01-143-08		
Jag 440 (all)	1988	01-143-120	01-105-01(PR)	
Jag 340 (all)	88-89	01-143-120	01-105-01(PR)	
Jag AFS (all)	89-93	01-143-120	01-105-01(PR)	
Jag (all)	90-94	01-143-120	01-105-01(PR)	
Jag 340 (all)	90-97	01-143-120	01-105-01(PR)	
Jag Deluxe, Z (except LC '96)	94-97	01-143-120		
Jag Liquid	1996	01-143-53		01-143-48(L)
Jag Deluxe	1997	01-143-120		
Jag 340, 440, Deluxe	98-00	01-143-63		
Jag 440 Deluxe	1999	01-143-63		
King Kat 900	04-06	01-143-63		01-145-05(ST)
Lynx 2000S	1980		01-099 (PR)	01-093(L)
Lynx 2000T (F2 Twin F/A)	77-78	01-143-08	01-143-30(PR)	01-093(L)
Lynx 2000T	79-80		01-092(P) 01-098(PR)	01-102(L)
Lynx II	1974	01-143-01	01-073	
Lynx AFS	91-93		01-143-30(PR)	
Jag 440 Deluxe	94-97	01-143-120	01-105-01(PR)	
Lynx 300, Deluxe	1991	01-143-120	01-105-01(PR)	
Lynx 340	92-93		01-105-01(PR)	
Lynx Wankel	71-74	01-143		
Mountain Cat 570	03-04	01-143-57		
Mountain Cat 5, 6, 8, 900	01-04	01-143-63		01-145-05(ST)



IGNITION COILS & LIGHTING COILS

Model	Year	External Ignition	Internal Ignition	Stator & Lightning Coils
Coils Codes: A = Primary A B = Primary B CH = Charging G = Generator IP Ignition & Primary L = Lighting P = Pulsation PR = Primary S = Source SR = Sensor ST = Stator				
Arctic Cat				
Mountain Cat 600 EFI	07-11	01-143-162		01-145-13(ST)
Mountain Cat 800 EFI	02-04	01-143-63		01-145-05(ST)
Mountain Cat 900 EFI	2004	01-143-63		01-145-05(ST)
M5	2005	01-143-162		
M5 EFI	2006			01-145-05(ST)
M6 EFI, (all)	05-08	01-143-162		
M7 (all)	05-06	01-143-162		
M8 (all)	07-14	01-143-76		01-145-13(ST)
M10 (all)	07-11	01-143-76		01-145-13(ST)
Pantera	76-78	01-143-06	01-092(P)	01-102(L)
Pantera F/C (all)	77-81	01-143-11		
Pantera	85-86	01-143-08	01-098-01(A) 01-098-02(B)	
Pantera	1987	01-143-120		
Pantera	1988	01-143-120	01-105-01(PR)	
Pantera	1989		01-105-01(PR)	
Pantera 440	90-92	01-143-53		01-143-48(L)
Pantera	93-97	01-143-120		
Pantera L/C	1996			01-143-48(L)
Pantera 550	97-05			01-145-07(ST)
Pantera 800	98-99	01-143-61 coil 1 01-143-62 coil 2		
Pantera 800 EFI	02-05	01-143-63		01-145-05(ST)
Panther	1972	01-143-111		
Panther	1973	01-143-01		
Panther 4000, 5000 (440, 500)	1976		01-143-30(PR)	
Panther Liquid	1996	01-143-53		
Panther Wankel	68-74	01-143		
Panther	74-75	01-143-120		
Panther 4000, 5000	76-79	01-143-08	01-096(SR)	01-093(L)
Panther	79-81/84	01-143-08	01-096(SR)	
Panther	85-87	01-143-08		
Panther	88-89	01-143-120	01-105-01(PR)	
Panther, Deluxe	90-96	01-143-120	01-105-01(PR)	
Panther 340, 440	98-00	01-143-63		
Panther 370	01-07	01-143-63		
Panther 570, ESR	03-07	01-143-57		
Panther 660 Trail, Touring	06-08	01-143-161		
Powder Extreme 600	97-98	01-143-61 coil 1 01-143-62 coil 2		
Powder Special EFI 500, 600	99-00	01-143-63		
Powder Special	92-97	01-143-120		01-145-07(ST)
Prowler 2-UP	90-93			01-143-48(L)
Prowler 2-UP	1995		01-105-01(PR)	01-145-07(ST)
Prowler 440	90-94	01-143-120		
Prowler MC	91-91			01-143-48(L)
Prowler Special	91-92	01-143-53	01-105-01(PR)	
Puma	1971			
Puma	1972	01-143-111		
Puma	1973	01-143		
Puma 2-Up, 340, Deluxe	94-96	01-143-120	01-105-01(PR)	
Sabercat 500, EFI	04-05	01-143-162		
Sabercat 500 EFI	2006	01-143-162		01-145-05(ST)
Sabercat 600 EFI	2004	01-143-162		01-145-05(ST)
Sabercat 600 (carb)	04-06	01-143-162		





IGNITION COILS & LIGHTING COILS

Model	Year	External Ignition	Internal Ignition	Stator & Lightning Coils
Coils Codes: A = Primary A B = Primary B CH = Charging G = Generator IP Ignition & Primary L = Lighting P = Pulsation PR = Primary S = Source SR = Sensor ST = Stator				
Arctic Cat				
Sabercat 600	05-06	01-143-162		
Sabercat 700 EFI	2004	01-143-162		01-145-05(ST)
Sabercat 700 EFI	05-06	01-143-162		
Sno-Pro 440	04-05	01-143-162		
Sno-Pro 500	10-14	01-143-76		01-145-13(ST)
Sno-Pro 600	09-12	01-143-76		
Super Jag	1987	01-143-08		
Super Jag	88-92	01-143-120	01-105-01(PR)	
T500 Touring	08-09	01-143-162		01-145-13(ST)
T570	08-13	01-143-157		
T660 (all)	04-06	01-143-161		
Thundercat, Mountain Cat	93-99	01-143-61 coil 1 01-143-62 coil 2		
Trail Cat (all)	79-81	01-143-11	01-096(SR)	
Touring, Trail 660	02-03	01-143-161		
VIP	1974		01-101(P)	
Widetrak	95-97	01-143-120		
WildCat 650 (all)	89-90	01-143-120	01-105-01(PR)	01-145-07(ST)
WildCat 700	91-93	01-143-120	01-105-01(PR)	01-145-07(ST)
WildCat EFI	90-96	01-143-120		
WildCat Touring	1995			01-145-07(ST)
XF800, XF8000 (all)	12-14	01-143-76		01-145-13(ST)
Z 370, ES, ESR	99-07	01-143-63		
Z 440, Sno-Pro	99-06	01-143-63		
Z 440	93-97	01-143-120		
Z 440	1995		01-105-01(PR)	
Z 440	98-02	01-143-63		
Z 570, LX, ESR, LX	03-07	01-143-57		
ZL 440	97-98	01-143-53		
ZL 500, EFI, ESR	99-02	01-143-63		
ZL 550	00-03			01-145-07(ST)
ZL 600, EFI, ESR, SS	99-02	01-143-63		
ZL 800, EFI, ESR, SS	01-03	01-143-63		01-145-05(ST)
ZR 400	93-95			01-145-07(ST)
ZR 440, 580, 700	93-97	01-143-120	01-105-01(PR)	
ZR 500, EFI	99-02	01-143-63		
ZR 580 (non EFI)	1996			01-145-07(ST)
ZR 5000	2014			01-145-13(ST)
ZR 600, EFI	99-02	01-143-63		
ZR 700	94-95			01-145-07(ST)
ZR 6000	2014	01-143-162		
ZR 800	2001	01-143-63		
ZR 800 EFI	02-03	01-143-63		01-145-05(ST)
ZR 800 Sno Pro	2003			01-145-05(ST)
ZR 8000	2014	01-143-76		01-145-13(ST)
ZR 900, Sno-Pro (carb)	03-06	01-143-63		01-145-05(ST)
ZR 900 EFI	04-06	01-143-63		01-145-05(ST)
ZRT 600, 700	95-99	01-143-61 coil 1 01-143-62 coil 2		



IGNITION COILS & LIGHTING COILS

Model	Year	External Ignition	Internal Ignition	Stator & Lightning Coils
Coils Codes: A = Primary A B = Primary B CH = Charging G = Generator IP Ignition & Primary L = Lighting P = Pulsation PR = Primary S = Source SR = Sensor ST = Stator				
Bombardier				
Alpine	66-67		01-142	
Alpine 300	1968		01-142	
Alpine 370	67-69	01-143		
Alpine 399	70-71	01-143		
Alpine 440	72-74	01-143		
Alpine 500	83-87	01-143-11		
Alpine 503, 2	83-89		01-079-01(G)	
Alpine 640	69-74	01-143		
Alpine 640	75-82	01-143		
Alpine II	88-90	01-143-11		
Alpine II	92-95	01-143-11		
Blizzard (all)	71-72	01-143		
Blizzard 292, 340	1970	01-143		
Blizzard 438, 636, 776	1970	01-143		
Blizzard 5500	79-81	01-143	01-143-32(G)	
Blizzard 5500 MX	82-84	01-143-11	01-079-01(G)	
Blizzard 7500	1981	01-143-11	01-143-30(PR)	01-087-04
Blizzard 9500	81-82	01-143-11	01-143-30(PR)	01-087-04
Blizzard 9700	83-84	01-143-11	01-079-01(G)	
BR	1964		01-142	
Cadet	72-75	01-143-02		
Capri 295	1972	01-143		
Capri 296	73-74	01-143		
Capri 340	1973	01-143-02		
Capri 440	1973	01-143-02		
Chalet	1965		01-142	
Cheyenne R, 90	1990	01-143-11		
Chimo	74-75	01-143		
Citation 300	78-79	01-143		
Citation 3500	80-81	01-143		01-087-04
Citation 3500	82-89	01-143-10	01-079-01(G)	
Citation 4500, E	80-81	01-143	01-143-32(G)	01-087-04
Citation 4500, E	82-83	01-143-11	01-079-01(G)	
Citation LS, LSE	85-88	01-143-10	01-079-01(G)	
Citation SS	80-81	01-143	01-143-32(G)	01-087-04
Citation SS	82-83	01-143-11	01-079-01(G)	
Citation, E	1991	01-079-01		
Elan (all)	73-76	01-143		
Elan 250	71-72		01-142	
Elan 250	77-96	01-143		
Elan 292 SS	71-72	01-143		
Elite	73-75	01-143		
Elite	78-80	01-143	01-143-32(G)	
Elite	81-82	01-143	01-143-30(PR)	
Escapade	87-88	01-143	01-079-01(G)	
Everest 340	77-79	01-143	01-143-32(G)	
Everest 440	74/76-79	01-143	01-143-32(G)	
Everest 440	1975	01-143-18		
Everest 444	78-79	01-143	01-143-32(G)	01-087-04
Everest 464	1980	01-143	01-143-32(G)	01-087-04
Everest 464	81-83	01-143-11	01-143-30(PR)	
Everest 500, E	80-81	01-143	01-143-32(G)	01-087-04
Everest 500, E	82-83	01-143-11		
Expedition 600 HO SDI	2005	01-143-149		
Expedition LE / SE 600 HO E-Tec	11-15	01-143-184		





IGNITION COILS & LIGHTING COILS

Model	Year	External Ignition	Internal Ignition	Stator & Lightning Coils
Coils Codes: A = Primary A B = Primary B CH = Charging G = Generator IP Ignition & Primary L = Lighting P = Pulsation PR = Primary S = Source SR = Sensor ST = Stator				
Bombardier				
Expedition Sport 600 Ace XP	11-14	01-143-183		
Expedition Sport 900 Ace XS	2014	01-143-183		
Expedition Sport V-800	2007	01-143-149		
Expedition TUV 600 HO SDI, TUV V-800	07-10	01-143-149		
F 296	1973	01-143		
F 340, 440	1973	01-143-02		
Formula 500	1998	01-143-70		
Formula 500 L/C	99-01	01-143-70		
Formula 500, 583	97-98	01-143-55		
Formula 583	1999	01-143-70		
Formula 670	1999	01-143-70		
Formula Deluxe 500, 600, 700	00-01	01-143-154		
Formula Deluxe 583	1998	01-143-70		
Formula Deluxe 670	1999	01-143-70		
Formula III LT	96-97	01-143-153		
Formula III 600, LT/R	1998	01-143-71		
Formula III 670	1999	01-143-71		
Formula III 700	98-99	01-143-71		
Formula III 700 R	98-00	01-143-71		
Formula III 800	99-00	01-143-71		
Formula Mach 1 (all)	89-90	01-143-11		
Formula Mach 1 (all except X)	91-92	01-143-11		
Formula Mach 1	93-95	01-143-55		
Formula Mach 1	98-99	01-143-71		
Formula Mach 1R	98-00	01-143-71		
Formula Mach 1X	1991	01-143-11		
Formula Mach I, Z, Z LT	96-97	01-143-153		
Formula Mach Z	98-00	01-143-71		
Formula Mach Z LT, LT R	98-99	01-143-71		
Formula Mach Z M.H.R	1999	01-143-71		
Formula Mach Z R	98-00	01-143-71		
Formula Mach Z, Sport/Tech	01-03	01-143-71		
Formula MX (all)	85-89	01-143-11		
Formula MX (all)	90-92	01-143-11		
Formula MX, MXZ	93-96	01-143-55		
Formula MXZ 440	1999	01-143-70		
Formula MXZ 500	98-99	01-143-70		
Formula MXZ 500	00-01	01-143-154		
Formula MXZ 500, 600, 700	2001	01-143-154		
Formula MXZ 583	1998	01-143-70		
Formula MXZ 600	99-00	01-143-154		
Formula MXZ 600 SB	2000	01-143-154		
Formula MXZ 670	1998	01-143-70		
Formula MXZ 670 HO	1999	01-143-70		
Formula MXZ 700 SB, Millennium E	2000	01-143-154		
Formula Plus	1993	01-143-55		
Formula Plus (all except X)	1992	01-143-11		
Formula Plus (all)	85-89	01-143-11	01-079-01(G)	
Formula Plus (all)	90-91	01-143-11		
Formula Plus X	1992	01-143-11		
Formula S, SL	1999	01-143-70		
Formula SP	85-86	01-143-11		
Formula SS	1985	01-143-11		
Formula SS, ST, STX, Z	94-97	01-143-55		
Formula Z	1997	01-143-55		



IGNITION COILS & LIGHTING COILS

Model	Year	External Ignition	Internal Ignition	Stator & Lightning Coils
Coils Codes: A = Primary A B = Primary B CH = Charging G = Generator IP Ignition & Primary L = Lighting P = Pulsation PR = Primary S = Source SR = Sensor ST = Stator				
Bombardier				
Formula Z 500	1999	01-143-70		
Formula Z 583	98-99	01-143-70		
Formula Z 670	98-99	01-143-70		
Formula, Z 600, 700	2000	01-143-154		
Futura 444	78-79	01-143	01-143-32(G)	01-087-04
Futura 295	1974	01-143		
Futura 300	1982	01-143-11		
Futura 340	1974	01-143-02		
Futura 400, E	77-79	01-143	01-143-32(G)	
Futura 440	1974	01-143	01-143-32(G)	
Futura 440, E	1975	01-143	01-143-32(G)	
Futura 440, E	76-79	01-143	01-143-32(G)	
Futura 464	1980	01-143	01-143-32(G)	01-087-04
Futura 464	1981	01-143-11	01-143-30(PR)	01-087-04
Futura 464	1982	01-143-11	01-143-30(PR)	
Futura 500, E	80-81	01-143	01-143-32(G)	
Futura 500, E	1982	01-143		
Grand Prix	70-71	01-143		
Grand Prix	71-72	01-143		
Grand Prix	1972	01-143-02		
Grand Sport	74-75	01-143-02		
Grand Touring, 470, 500, 580, 670	93-97	01-143-55		
Grand Touring 500	2001	01-143-154		
Grand Touring 500	02-03	01-143-70		
Grand Touring 500, 583	98-99	01-143-70		
Grand Touring 600	00-01	01-143-154		
Grand Touring 600 Sport	2009	01-143-224		
Grand Touring 700	98-00	01-143-71		
Grand Touring 700	2001	01-143-154		
Grand Touring 800	2001	01-143-71		
Grand Touring 800 SDI	2003	01-143-149		01-245-01 (ST)
Grand Touring LE 600 HO ETEC	10-15	01-143-184		
GSX 500 SS	04-06	01-143-150		01-245-01 (ST)
GSX 500 SS, Sport	06-08	01-143-224		01-245-01 (ST)
GSX 500 SS, Sport	2009	01-143-224		
GSX 600 HO	04-05	01-143-150		01-245-01 (ST)
GSX 600 HO SDI	04-07	01-143-149		
GSX 600 Sport	2010	01-143-224		
GSX 600 HO ETEC	09-15	01-143-184		
GSX 800 HO	04-06	01-143-224		01-245-01 (ST)
GSX 800 HO, LTD R	05-08	01-143-224		
GSX LE 900 Ace XS	2014	01-143-183		
GSX LTD 800 HO PTEK	2007	01-143-224		01-245-01 (ST)
GSX LTD 800R	2008	01-143-224		
GSX SE 800R ETEC	12-15	01-143-184		
GTX 500 SS	2005	01-143-150		01-245-01 (ST)
GTX 500 SS	2006	01-143-224		01-245-01 (ST)
GTX 500 SS Sport	06-08	01-143-224		01-245-01 (ST)
GTX 600 HO	2005	01-143-150		
GTX 600 HO SDI / Sport SDI	05-08	01-143-149		
GTX 600 HO ETEC	2009	01-143-184		
GTX 800 HO	00-02	01-143-224		
GTX 800 HO	05-06	01-143-224		01-245-01 (ST)
GTX LTD 800 HO PTEK	2007	01-143-224		01-245-01 (ST)
GTX RFI	00-02	01-143-149		





IGNITION COILS & LIGHTING COILS

Model	Year	External Ignition	Internal Ignition	Stator & Lightning Coils
Coils Codes: A = Primary A B = Primary B CH = Charging G = Generator IP Ignition & Primary L = Lighting P = Pulsation PR = Primary S = Source SR = Sensor ST = Stator				
Bombardier				
Legend 500, SS	02-04	01-143-70		01-245-01 (ST)
Legend 600, 700	02-04	01-143-70		01-245-01 (ST)
Legend 600 HO SDI / 800 SDI	2004	01-143-149		
Legend 800	2002	01-143-70		
Legend SE 800 SDI	2003	01-143-149		
Legend Touring V-800, Trail V800	2007	01-143-149		
Mach 1	85-89		01-079-01(G)	
Mach Z 1000 SDI (all)	05-06	01-143-149		
Mach Z Adrenaline / X	2007	01-143-149		
Mirage 300	1979	01-143		
Mirage I	80-81	01-143		01-087-04
Mirage I	1982	01-143-10		
Mirage II	80-81	01-143	01-143-32(G)	01-087-04
Mirage II	82-83	01-143-11		
Mirage III	1985	01-143-11		
Mirage Special	80-81	01-143	01-143-32(G)	
Mirage Special	1982	01-143-11		
MX	79-81	01-143	01-143-32(G)	01-087-04
MXZ 1000 SDI, Mach Z, X	05-07	01-143-224		
MXZ 440, 583	96-97	01-143-55		
MXZ 440	06-07	01-143-224		01-245-01 (ST)
MXZ 500	00-03	01-143-154		01-245-01 (ST)
MXZ 500 SS	04-05	01-143-150		
MXZ 500 SS	07-08	01-143-224		01-245-01 (ST)
MXZ 500 SS Adrenaline	2007	01-143-224		
MXZ 500 SS TNT	08-09	01-143-224		
MXZ 500 SS Trail	07-08	01-143-224		
MXZ 600	99-03	01-143-154		
MXZ 600 HO, Adrenaline	04-07	01-143-224		01-245-01 (ST)
MXZ 600 HO Adrenaline (non SDI)	06-07	01-143-224		
MXZ 600 HO Renegade, Trail	04-05	01-143-224		01-245-01 (ST)
MXZ 600 HO REV	03-05	01-143-150		01-245-01 (ST)
MXZ 600 HO SDI	04-07	01-143-149		
MXZ 600 HO ZX	2003	01-143-70		
MXZ 600 RS	08-09	01-143-224		
MXZ 600 Sport, TNT	10-11	01-143-224		
MX Z 600 TNT	2009	01-143-224		01-245-01 (ST)
MXZ 700	99-02	01-143-154		
MXZ 700	2003	01-143-154		01-245-01 (ST)
MXZ 800	02-03	01-143-70		
MXZ 800 Adrenaline, X with DPM	04-05	01-143-224		01-245-01 (ST)
MXZ 800 Adrenaline, X without DPM	04-06	01-143-150		01-245-01 (ST)
MXZ 800 HO Adrenaline	05-06	01-143-224		
MXZ 800 HO PTEK Adrenaline	2007	01-143-224		01-245-01 (ST)
MXZ 800 HO PTEK Blizzard	2007	01-143-224		01-245-01 (ST)
MXZ 800 HO PTEK Renegade, X	2008	01-143-224		01-245-01 (ST)
MXZ 800 HO Renegade, X	05-06	01-143-224		
MXZ 800 HO X without DPM	05-06	01-143-224		
MXZ 800 REV	02-03	01-143-150		01-245-01 (ST)
MXZ 800R Adrenaline	2008	01-143-224		
MXZ 800R Adrenaline PTEK	09-10	01-143-224		
MXZ 800R Renegade, X	2008	01-143-224		
MXZ 800R Renegade, X PTEK	2009	01-143-224		
MXZ 800R ETEC (all)	11-15	01-143-184		
MXZ TNT 900 Ace XS	11-14	01-143-183		



IGNITION COILS & LIGHTING COILS

Model	Year	External Ignition	Internal Ignition	Stator & Lightning Coils
Coils Codes: A = Primary A B = Primary B CH = Charging G = Generator IP Ignition & Primary L = Lighting P = Pulsation PR = Primary S = Source SR = Sensor ST = Stator				
Bombardier				
MXZ 1000 SDI Renegade	06-07	01-143-149		
MXZ Renegade, X	2004	01-143-224		01-245-01 (ST)
MXZ Renegade, X	05-06	01-143-224		01-245-01 (ST)
MXZ Sport 600 Ace XP	11-14	01-143-183		
MXZ TNT	2008	01-143-224		
MXZ TNT 900 Ace XS	11-14	01-143-183		
MXZ Trail	2009	01-143-224		
MXZ X 440	06-07	01-143-224		
MXZ X 600 RS	09-10	01-143-224		
MXZ X 600 HO ETEC (all)	09-15	01-143-184		
MXZ X 800R PTEK	09-10	01-143-224		
MXZ XRS 800 HO PTEK	07/10	01-143-224		
Nordic	1981	01-143	01-143-32(G)	
Nordic	82-83	01-143-11		
Nordic (all)	69-73	01-143		
Nordic 640	1974	01-143-18		
Nuvik 300, 300E, 340, 340E	1975	01-143		
Nuvik 300, 300E, 340, 340E	76-79	01-143	01-143-32(G)	
Nuvik 440, E	1977	01-143	01-143-32(G)	
Olympic	65-67		01-142	
Olympic (all)	73-74	01-143		
Olympic 250	1968		01-142	
Olympic 300	69-72	01-143-11	01-142	
Olympic 300M	75-77	01-143		
Olympic 300T	75-78	01-143	01-143-32(G)	
Olympic 320	69-71	01-143		
Olympic 335	70-73	01-143		
Olympic 340, E	75-79	01-143	01-143-32(G)	
Olympic 370	68-69	01-143		
Olympic 399	69-72	01-143		
Olympic 440	75-77	01-143	01-143-32(G)	
Olympic 440	1976	01-143		
Olympic TNT	1970		01-142	
RD	1964		01-142	
Renegade 600 HO ETEC (all)	10-15	01-143-184		
Renegade 800R ETEC (all)	10-15	01-143-184		
Renegade 800R PTEK Adrenaline	2010	01-143-224		
Renegade 800R PTEK BackCountry, X	2010	01-143-224		
Renegade Adrenaline 900 Ace XS	2014	01-143-183		
Renegade Sport 600 Ace XP	11-14	01-143-183		
Renegade X 800R PTEK	10-11	01-143-224		
RV (all)	76-77	01-143-18		
RV 250	1975	01-143-18		
RV 340	1978	01-143-18		
RV Cross Country	1978	01-143-18		
S 400	1973	01-143		
Safari (all)	84-88	01-143-11		
Safari Cheyenne	1989	01-143-11		
Safari Citation, E	89-91	01-143-10		
Safari Escapade	1989	01-143-11		
Safari GLX, LC	90-92	01-143-11		
Safari L, LE	1990	01-143-11		
Safari Saga	1989	01-143-11		
Safari Scout, E	89-90	01-143-11		
Safari Voyageur	1989	01-143-11		





IGNITION COILS & LIGHTING COILS

Model	Year	External Ignition	Internal Ignition	Stator & Lightning Coils
Coils Codes: A = Primary A B = Primary B CH = Charging G = Generator IP Ignition & Primary L = Lighting P = Pulsation PR = Primary S = Source SR = Sensor ST = Stator				
Bombardier				
Skandic 277	1983	01-143-10		
Skandic 335	70-72		01-142	
Skandic 335	1973	01-143		
Skandic 377, 503	92-93	01-143-11		
Skandic 377, R	82-87	01-143-11		
Skandic 500	2002	01-143-150		
Skandic 500F, 600	2001	01-143-154		
Skandic 503	1987	01-143-11		
Skandic 600 (all)	02-07	01-143-150		
Skandic WT600	08-10	01-143-224		01-245-01 (ST)
Skandic SWT	2000	01-143-70		
Skandic SWT, WT 500F	2003	01-143-150		
Skandic SWT V-800	07-12	01-143-149		
Skandic SWT / WT 600 Ace XU	11-14	01-143-183		
Skandic 600 HO ETEC SWT / WT	11-15	01-143-184		
Skandic Tundra V-800	2007	01-143-149		
Skandic WT L/C	1998	01-143-55		
Skandic WT L/C	2000	01-143-70		
Sonic	1982	01-143-11		
Sonic 250	1976	01-143-18		
Sonic 340	1975	01-143-18		
Sonic 340	76-78	01-143-18		
Sonic Cross Country	1978	01-143-18		
Sonic L/C	1984	01-143-11	01-143-30(PR)	
Spirit	76-83	01-143-11		
SS-25	1984	01-143-11	01-143-30(PR)	
Stratos, E	87-88	01-143-11		
Summit 50th Anniversary	2009	01-143-224		
Summit 500	98-99	01-143-70		
Summit 500, 583, 670	94-97	01-143-55		
Summit 500 SS Everest	2009	01-143-224		
Summit 583	1998	01-143-70		
Summit 600	99-01	01-143-154		
Summit 600	02-07	01-143-70		
Summit 600 HO	03-05	01-143-150		01-245-01 (ST)
Summit 600 HO SDI Adrenaline	06-07	01-143-149		
Summit 600 Sport	2010	01-143-224		
Summit 670	1998	01-143-70		
Summit 700, 800	02-03	01-143-70		
Summit 700, SB	99-00	01-143-154		
Summit 800 HI, R (all)	06-08	01-143-224		
Summit 800 HO	03-06	01-143-150		01-245-01 (ST)
Summit 800 HO	06-08	01-143-224		01-245-01 (ST)
Summit 800R PTEK Everest	09-10	01-143-224		
Summit 1000 SDI Highmark, Highmark X	05-07	01-143-149		
Summit Highmark	2000	01-143-154		
Summit Hill Climb	09-10	01-143-224		
Summit X	2007	01-143-224		01-245-01 (ST)
Summit X 670	98-99	01-143-70		
Summit X 800R PTEK	09-10	01-143-224		
Super Sonic	1981	01-143	01-143-30(PR)	
TNT F/A	74-75	01-143-18		
TNT F/A	77-78	01-143	01-143-32(G)	
TNT (all F/C)	72-74	01-143		
TNT F/C	75-78	01-143		



IGNITION COILS & LIGHTING COILS

Model	Year	External Ignition	Internal Ignition	Stator & Lightning Coils
Coils Codes: A = Primary A B = Primary B CH = Charging G = Generator IP Ignition & Primary L = Lighting P = Pulsation PR = Primary S = Source SR = Sensor ST = Stator				
Bombardier				
TNT 292	70-71		01-142	
TNT 294, 300	1973	01-143		
TNT 340 F/A	1973	01-143		
TNT 340 F/C	70-71		01-142	
TNT 340 F/C	72-73	01-143		
TNT 340 F/C	1974	01-143	01-143-32(G)	
TNT 399 F/C	69-70	01-143		
TNT 400 F/A	72-73	01-143		
TNT 440 F/C	71-72	01-143		
TNT 440, E F/C	73-74	01-143		
TNT 640 F/C, 775 F/C	70-72	01-143		
TNT 669 F/C	1969	01-143		
Touring 500 L/C	2000	01-143-70		
TS-400	74-75	01-143		
Tundra II, LT	92-99	01-143-64		
Tundra, LT	85-90	01-143-10		
Ultra Sonic	81-82	01-143	01-143-30(PR)	
Valmont	71-73	01-143		
Zephyr	72-73	01-143-02		
CCW / Kiortz				
290, 340		01-143-02		
340S 175		01-143-11		
440, 440		01-143-02		
KEC 340, 400, 440, 22		01-143-09		
Hirth Engines				
All Single Cylinders without external ignition coils			01-142	
All Single Cylinders with external ignition coils		01-143		
JLO (Rockwell) Engines				
All Single Cylinders without external ignition coils			01-142	
All Single Cylinders with external ignition coils		01-143		
All Multi Cylinders with point type ignition		01-143		
John Deere				
300	74-77	01-143		
400	72-75	01-143-02		
400	1976	01-143-09		
500	72-74	01-143-02		
600	73-75	01-143-02		
800	1975	01-143-02		
Cyclone	76-78	01-143-09		
JD 295, S	74-75	01-143-09		
JDX 4, 6, 8	73-75	01-143-02		
Liquidator	1976	01-143-09		
Liquifire	76-78	01-143-09		
Liquifire	80-81	01-143-19		
Spitfire	78-79	01-143-11		
Trailfire 340	79-80	01-143-11		
Trailfire 400 (all)	79-84	01-143-19		
Kawasaki				
Astro 340, 440	1977	01-143-111		
Drifter 340	1979	01-143-111		
Drifter 440	1979	01-143-19	01-092(P)	
Drifter 440	1980	01-143-19		
Intriguer 440	1978	01-143-19	01-092(P)	
Intriguer 440	1979	01-143-19		
Intruder 440	78-79	01-143-19	01-092(P)	





IGNITION COILS & LIGHTING COILS

Model	Year	External Ignition	Internal Ignition	Stator & Lightning Coils
Coils Codes: A = Primary A B = Primary B CH = Charging G = Generator IP Ignition & Primary L = Lighting P = Pulsation PR = Primary S = Source SR = Sensor ST = Stator				
Kawasaki				
Intruder 440	1980	01-143-19	01-083-05(E)	
Invader 340	1978	01-143-01	01-092(P)	
Invader 340	1979		01-092(P)	
Invader 340	1980		01-083-05(E)	
Invader 440	78-79		01-092(P)	
Invader 440	80-81	01-143-19	01-083-05(E)	
Inviter 440	78-79	01-143-19		
200 (75 watt)	70-71	01-143		
Lighting	71-72	01-143-02		
Max 440	73-74	01-143-02		
M, X440	1975	01-143-02		
Snow-Twister, Trail Twister	74-76	01-143-01		
S, R340	1975	01-143-01		
S, R440	74-75	01-143-02		
Polaris				
340 Edge Touring LX	04-08	01-143-112		
440 IQ	05-07	01-143-69		
500 Classic, Edge	01-03	01-143-69		
500 RMK	2000	01-143-69		
550 Classic, Edge LX	06-08	01-143-112		
600 Classic, Edge RMK	02-06	01-143-69		
600 Edge Touring	05-06	01-143-69		
600 HO, Fusion, RMK	2006	01-143-69		
600 HO Switchback	04-07	01-143-69		
600 IQ (all)	08-09	01-143-69		
600 Pro-X, X2	03-04	01-143-69		
600 RMK	02-08	01-143-69		
600 RR	08-09	01-143-69		
600 XC Special (US made)	01-05	01-143-69		
700 Classic, all	02-04	01-143-69		
700 Pro-X, RMK, SKS, XC/SP	01-05	01-143-69		
700 Classic, Fusion, HO, RMK (US made)	2006	01-143-114 PTO 01-143-98 MAG		
800 Classic	2004	01-143-69		
800, LE,RMK,HO, Edge, X, SP	01-05	01-143-69		
900 Fusion, RMK, Switchback	05-06	01-143-114 PTO 01-143-98 MAG		
Apollo 340	79-80	01-143-04	01-073	01-084-05(L)
Centurion Indy 500	79-82	01-143-13		
Charger 295	72-73	01-143-04		01-084-05
Charger 400	1972	01-143-04		
Charger 400	1973	01-143-04		
Charger 530	1972	01-143-05		01-084-05
Charger SS 400	1972	01-143-04		
Charger SS 530	1972	01-143-05		
Cobra 340	78-79	01-143-04		01-084-05
Cobra 440	78-79	01-143-04		01-084-05
Colt 175	73-74/76	01-143-04		
Colt 244	1974			
Colt 250	75-78	01-143-04	01-073	01-084-05(L)
Colt 250S	72-74 / 76-78	01-143-04		
Colt 295	1974	01-143-04		
Colt 295	1972	01-143-04		
Colt 295	1973	01-143-04		
Colt 340	75-76	01-143-04		01-084-05



IGNITION COILS & LIGHTING COILS

Model	Year	External Ignition	Internal Ignition	Stator & Lightning Coils
Coils Codes: A = Primary A B = Primary B CH = Charging G = Generator IP Ignition & Primary L = Lighting P = Pulsation PR = Primary S = Source SR = Sensor ST = Stator				
Polaris				
Colt 340	1972	01-143-04		
Colt SS 250T	74-76	01-143-04		
Colt SS 250T	1977	01-143-04		01-084-05
Colt SS 295	72-74	01-143-04		
Colt SS 340	72-74 / 76-77	01-143-04	01-073	01-084-05(L)
Custom 400	1973	01-143-04		
Custom 530	1973	01-143-04		
Custom II 250SS	1974	01-143-04		
Custom II 400	1974	01-143-04		01-084-05
Custom II 530	1974	01-143-05		
Cutlass 340	1981	01-143-04	01-073	01-084-05(L)
Cutlass SS 440	81-82		01-077-01(P)	
Electra 250S	75-77	01-143-04		
Electra 340	74-76	01-143-05		
Electra 340	1977	01-143-04	01-073	01-084-05(L)
Electra 440	74-76	01-143-05		
Electra 440	1977	01-143-04	01-073	01-084-05(L)
Galaxy 340, E	1980	01-143-04		01-084-05
Galaxy 440, E	80-81	01-143-04		01-084-05
Gemini 250 Single	79-81,83	01-143-04		
Gemini 250 Twin	79-81	01-143-04	01-073	01-084-05(L)
Indy 440 Pro-X	01-04	01-143-69		
Indy 440 XC SP	2000	01-143-69		
Indy 440 XCR SP	1999	01-143-69		
Indy 500 XC (all)	01-08	01-143-69		
Indy 500 XC (all)	1982	01-143-13		
Indy 500, SKS	1989		01-077-01(P)	
Indy 500 Classic	1989		01-077-01(P)	
Indy 600 (all)	83-87	01-143-13	01-084-09	
Indy 600 Classic Edge	01-02	01-143-69		
Indy 600 XC SP	00-02	01-143-69		
Indy 650 (all)	88-90	01-143-13	01-084-09	
Indy 700 Classic, RMK, SKS	02-04	01-143-69		
Indy 700 XC SP	01-02	01-143-69		
Indy 800 RMK	00-02	01-143-69		
Indy 800 XC SP	01-02	01-143-69		
Indy 800 XCR	2002	01-143-67		
Indy Cross Country	1983	01-143-05		
Indy Storm	96-98	01-143-67		
Indy Trail 440	83-85		01-077-01(P)	01-084-03 (L)
Indy Trail 488 (all)	85-89		01-077-01(P)	01-084-03 (L)
Indy Ultra (all)	96-98	01-143-67		
Indy XCR 600	95-96	01-143-60		
Indy XLT, Special	93-98	01-143-60		
Long Track (LT,LTR) 440	84-89		01-077-01(P)	01-084-03 (L)
Mustang 400	1972	01-143-04		
Mustang 400	1973	01-143-04		
Mustang 530	72-73	01-143-05		
Sport Touring	03-04	01-143-112		
Supersport, Edge, X, M-10	03-08	01-143-112		
Sport 440	1983		01-077-01(P)	01-084-03 (L)
SS 340	1978	01-143-04		01-084-05
SS 440	83-86		01-077-01(P)	01-084-03 (L)
Fujifire 250	1976	01-143-05		
Fujifire 340	1976	01-143-05		





IGNITION COILS & LIGHTING COILS

Model	Year	External Ignition	Internal Ignition	Stator & Lightning Coils
Coils Codes: A = Primary A B = Primary B CH = Charging G = Generator IP Ignition & Primary L = Lighting P = Pulsation PR = Primary S = Source SR = Sensor ST = Stator				
Polaris				
Trail RMK, Touring, Deluxe	06-08	01-143-112		
TC 175	74-75	01-143-05		
TC 244S	74-75	01-143-04		
TX 250	74-77	01-143-05		
TX 250	78-79	01-143-05		
TX 295	72-73	01-143-05		
TX 340	72-77	01-143-05		
TX 340	78-80	01-143-05		
TX 400	1973	01-143-05		
TX 440	73-77	01-143-05		
TX 440	78-80	01-143-05		
TX 440	1977	01-143-05		
TX-C 340	79-80	01-143-05		
TX-C 440	81-82		01-077-01(P)	
TXL 340	1977	01-143-05		
TXL 340	78-82	01-143-05		
TXL 340 Indy	80-82	01-143-05		
XC 600	1997	01-143-60		
XCR 600	95-96	01-143-60		
XCR 600, SE	97-98	01-143-67		
XCR 700	98-99	01-143-67		
XCR 800	1999	01-143-67		
XLT (all mono-block triples)	93-99	01-143-60		
Rupp				
All Models	70-72	01-143-02		
Magnum 250	76-77	01-143-33		01-143-34
Nitro	74-75	01-143-09		
Nitro 250	1977			01-143-34
Nitro 440	76-78	01-143-33		01-143-34
Rally	1976	01-143-09		
Rally	1978	01-143-02		
Sachs Engines				
All Single Cylinders without external ignition coils			01-142	
All Single Cylinders with external ignition coils		01-143		
All Multi Cylinders with point type ignition		01-143		
Scorpion				
Lil Whip 290	78-79	01-143	01-143-32(G)	01-143-34
Range Whip	1978	01-143	01-143-32(G)	01-070 / 01-071
Sidewinder	1981		01-143-30(PR)	01-093(L)
Sting	79-80	01-143	01-143-32(G)	01-070 / 01-071
TK	80-81	01-143	01-143-32(G)	01-070 / 01-071
Whip 340	75-78	01-143	01-143-32(G)	01-143-34
Sno-Jet				
Astro	1977	01-143-111		
Astro Jet	74-76	01-143-17		
Sabre Jet 440	1974	01-143-17		
SS Jet	1971	01-143-17		
SST F/A	1975	01-143-16		
SST F/C	72-76	01-143-17		
SST F/C	1977	01-143-15		
Star Jet (all)	71-73	01-143-17		
Super Jet	71-72	01-143-17		
Thunder Jet	73/75	01-143-16		
Whisper Jet	73-75	01-143-17		



IGNITION COILS & LIGHTING COILS

Model	Year	External Ignition	Internal Ignition	Stator & Lightning Coils
Coils Codes: A = Primary A B = Primary B CH = Charging G = Generator IP Ignition & Primary L = Lighting P = Pulsation PR = Primary S = Source SR = Sensor ST = Stator				
Yamaha				
All Models (except SR)	71-73	01-143-17		
All Models (except GPX)	74-75	01-143-17		
Apex (all)	06-11	01-143-68		
Attak, GT	06-07	01-143-68		
Bravo	2007	01-143-68		
BR 250 Bravo	82-88	01-143-50	01-085-25(CH)	01-085-31
Bravo 250 (all)	89-00	01-143-52		
Excel III (EC 340)	79-83	01-143-15		01-085-05
Excel III (EC 340)	84-86	01-143-14		01-085-09
Excel III (EC 340)	87-88	01-143-14	01-085-22(CH)	01-085-20 / 01-085-21
Excel V (XL 540)	79-82	01-143-15		
Excel V (XL 540)	1983	01-143-15	01-085-23(CH)	
Excel V (XL 540)	85-90			01-085-09
Enticer 250 (ET 250)	77-81	01-143-17		
Enticer 300 (ET 300)	79-81/83	01-143-15		01-085-04
Enticer 300 (ET 300)	1984	01-143-14		01-085-09
Enticer 340 (all)	78-83	01-143-15	01-085-23(CH)	01-085-04
Enticer 340 (all)	84-86	01-143-14		01-085-09
Enticer 340 (all)	87-88	01-143-14	01-085-22(CH)	01-085-21
Enticer LTR (ET 400)	89-90	01-143-14		01-085-20
Enticer II LT (ET 410)	91-95	01-143-14		01-085-20
Exciter (EX 340)	1976	01-143-16		
Exciter (EX 340)	77-78	01-143-15		01-085-16 / 01-085-18
Exciter (EX 440)	1976	01-143-16		
Exciter (EX 440)	77-81	01-143-15		01-085-18
Exciter (EX 570)	87-90			01-085-09 / 01-085-05 / 01-085-06
Exciter (EX 570)	91-93	01-143-14		
GP 300	1976	01-143-17		
GP 440	76-78	01-143-17		
GPX	74-75	01-143-16		
GS 300	76-77	01-143-17		
GS 340	1976	01-143-17		
GS 340	1977	01-143-17		
Inviter (CF 300)	86-88	01-143-50		
Mountain Lite 500	00-01	01-143-14		
Mountain Max 600	00-01	01-143-65		
Mountain Max 700	97-00	01-143-65		
Nytro (all)	06-11	01-143-59		
500 Phazer, Deluxe, MT	00-01	01-143-14		
500 Venture	00-01	01-143-51		
500 V-Max, Deluxe	00-01	01-143-51		
SX 500	00-01	01-143-51		
Ovation (CS 340)	89-99	01-143-14		
Phazer (PZ 480 F/C)	1984	01-143-14		01-085-09 / 01-085-05
Phazer (PZ 480 F/C)	85-87	01-143-14		01-085-09 / 01-085-05 / 01-085-06
Phazer (PZ 480 F/C)	1988	01-143-14		01-085-05 / 01-085-06
Phazer (PZ 480 F/C)	1989			01-085-09 / 01-085-05 / 01-085-06
Phazer II (PZ 480 F/C)	90-96			01-085-09
Phazer II (PZ 480 F/C)	93-98	01-143-51		
Phazer (all)	07-11	01-143-68		
Phazer 500	99-01	01-143-14		
Phazer Mountain 480	1999	01-143-51		
Prestige	76-77	01-143-17		
Rage, GT	06-07	01-143-59		
RS Rage	2005	01-143-59		












IGNITION COILS & LIGHTING COILS

Model	Year	External Ignition	Internal Ignition	Stator & Lightning Coils
Coils Codes: A = Primary A B = Primary B CH = Charging G = Generator IP Ignition & Primary L = Lighting P = Pulsation PR = Primary S = Source SR = Sensor ST = Stator				
Yamaha				
RS Venture (all except Lite)	05-06 / 08-11	01-143-59		
RS Viking	2008	01-143-59		
RX-1	03-05	01-143-73		
RX-1 Mountain, LE	03-05	01-143-73		
RX-1 ER, LE	03-05	01-143-73		
RX-1 LE	03-04	01-143-73		
RX Warrior, LE	04-05	01-143-73		
SR	1973	01-143-16		
SRV (SR 540 F/C)	80-83	01-143-15		
SRV (SR 540 F/C)	84-88	01-143-14		01-085-09 / 01-085-06
SRV (SR 540 F/C)	89-91			01-085-09 / 01-085-06
SRX 340	1976	01-143-16		
SRX 440	1976	01-143-16		
SRX 440	77-80	01-143-15		
SRX 500	2001	01-143-51		
SS 440	80-83	01-143-15		
SS 440	1984	01-143-14		
SS 440	1985	01-143-14		01-085-09 / 01-085-06
SSR 440	1978	01-143-15		
SV 125 Sno Sport	91-92	01-143-52		
SX Venom	04-06	01-143-121		
SX Venom,ER	04-05	01-143-121		
SX Viper ER	2004	01-143-121		
SX Viper Mountain	2005	01-143-121		
SXR 600, 700	00-01	01-143-65		
Vector (all)	05-11	01-143-59		
Venture 480 GT	92-93			01-085-09
Venture 480, 500, 600	91-98	01-143-51		
Venture 480 TF	99-01	01-143-51		
Venture 500	99-01	01-143-51		
Venture 500 XL	99-01	01-143-14		
Venture 600	99-00	01-143-65		
Venture 600	01-03 / 05-06	01-143-121		
Venture 600	2004	01-143-51		
Venture 700	98-00	01-143-65		
Viking (VK 540)	83-91	01-143-15		
Viking (VK 540)	1992	01-143-14		
Viking (VK 540)	93-02	01-143-51		
V-Max (VMX 540 L/C)	83-87	01-143-17		
V-Max 500, 600	94-00	01-143-51		
V-Max 500 SX, Deluxe	99-01	01-143-51		
V-Max 600 SX, Deluxe	99-01	01-143-65		
V-Max 700 SX, Deluxe	97-00	01-143-65		
V-Max 750, 800	92-97	01-143-14		
Excel V (XL 540)	85-88	01-143-14		01-085-05 / 01-085-06
Excel V (XL 540)	89-90			01-085-05 / 01-085-06
VK Pro	06-11	01-143-59		

IGNITION COILS & LIGHTING COILS

			
01-068-02 External Coil	01-070 Lighting Coil	01-071 Lighting Coil	01-073 Internal Coil
			
01-077-01 Internal Coil	01-079-01 External Coil	01-083-05 Internal Coil	01-084-03 Lighting Coil
			
01-084-05 Internal Coil	01-084-09 Lighting Coil	01-085-04 Lighting Coil	01-085-05 Lighting Coil
			
01-085-06 Lighting Coil	01-085-09 Internal Coil	01-085-16 Lighting Coil	01-085-18 Lighting Coil
			
01-085-20 Lighting Coil	01-085-21 Lighting Coil	01-085-22 Charging Coil	01-085-23 Internal Coil
			
01-085-25 Lighting Coil	01-085-31 Lighting Coil	01-087-04 Lighting Coil	01-092 Internal Coil

IGNITION COILS & LIGHTING COILS

			
01-093 Lighting Coil	01-09 Internal Coil	01-098 Internal Coil	01-098-01 Internal Coil
			
01-098-02 Internal Coil	01-099 Internal Coil	01-100 Internal Coil	01-101 Internal Coil
			
01-102 Lighting Coil	01-105-01 Primary Coil	01-107-03 Lighting Coil	01-142 Internal Coil
			
01-143 External Coil	01-143-01 External Coil	01-143-02 External Coil	01-143-04 External Coil
			
01-143-05 External Coil	01-143-06 External Coil	01-143-08 External Coil	01-143-09 External Coil
			
01-143-10 External Coil	01-143-11 External Coil	01-143-13 External Coil	01-143-14 External Coil

IGNITION COILS & LIGHTING COILS



01-143-15
External Coil



01-143-16
External Coil



01-143-17
External Coil



01-143-18
External Coil



01-143-19
External Coil



04-143-30
Internal Primary Coil




01-143-32
Internal Coil



01-143-33
External Coil




01-143-34
Lighting Coil



01-143-48
Lighting Coil



01-143-50
External Coil



01-143-51
External Coil



01-143-52
External Coil



01-143-53
External Coil



01-143-55
External Coil



01-143-57
External Coil



01-143-59
External Coil



01-143-60
External Coil



01-143-61
External Coil




01-143-62
External Coil



01-143-63
External Coil



01-143-64
External Coil



01-143-65
External Coil



01-143-67
External Coil

IGNITION COILS & LIGHTING COILS



01-143-68
External Coil



01-143-69
External Coil



01-143-70
External Coil



01-143-71
External Coil



01-143-73
External Coil



01-143-76
External Coil



01-143-79
External Coil



01-143-98
External Coil



01-143-111
External Coil



01-143-112
External Coil



01-143-114
External Coil



01-143-120
External Coil



01-143-121
External Coil



01-143-149
External Coil



01-143-150
External Coil



01-143-153
External Coil



01-143-154
External Coil



01-143-157
External Coil



01-143-161
External Coil



01-143-162
External Coil



01-143-183
External Coil



01-143-184
External Coil



01-145-05
Stator



01-145-07
Stator

IGNITION COILS & LIGHTING COILS



01-143-13
Stator



01-245-01
Stator